

Enna Dining









Underframe Model: END110

25W 25.5D 38H 26AH

Enna Dining Chair, without X Enna Dining Chair, without X Enna Dining Chair, with X Underframe, with X Back Insert Model: END110I 25W 25.5D 38H

26AH

Underframe Model: END111 25W 25.5D 38H 26AH

Enna Dining Chair, with X Underframe, with X Back Insert Model: END1111 25W 25.5D 38H 26AH