





## Monserato Lounge




Monserato Lounge Chair,  
with Button Detail, without  
Seat Rail

Model: MSRR111  
29W 28.75D 33H  
25AH




Monserato Lounge Chair,  
with Button Detail, with Seat  
Rail

Model: MSRR112  
29W 28.75D 33H  
25AH



Monserato Lounge Chair,  
without Button Detail,  
without Seat Rail

Model: MSRR121  
29W 28.75D 33H  
25AH



Monserato Lounge Chair,  
without Button Detail, with  
Seat Rail

Model: MSRR122  
29W 28.75D 33H  
25AH