



Toni Stack




Toni Stacking Side Chair,
Queen Anne Legs, Armless,
Seat Pad, Round Back
Model: 992005
19.75W 22.5D 39H




Toni Stacking Side Chair,
Queen Anne Legs, Armless,
Plush Seat, Round Back
Model: 992065
20.75W 22.5D 39H




Toni Stacking Chair, Queen
Anne Legs, Straight T Arm,
Seat Pad, Round Back
Model: 992105
24.75W 22.5D 39H
25AH



Toni Stacking Chair, Queen
Anne Legs, Straight T Arm,
Plush Seat, Round Back
Model: 992165
24.75W 22.5D 39H
25AH




Toni Stacking Chair, Queen
Anne Legs, Gooseneck Arm,
Seat Pad, Round Back
Model: 992205
24.75W 22.5D 39H
25.5AH




Toni Stacking Chair, Queen
Anne Legs, Gooseneck Arm,
Plush Seat, Round Back
Model: 992265
24.75W 22.5D 39H
25.5AH




Toni Stacking Chair, Queen
Anne Legs, Waterfall Arm,
Seat Pad, Round Back
Model: 992305
24.75W 22.5D 39H
25AH




Toni Stacking Chair, Queen
Anne Legs, Waterfall Arm,
Plush Seat, Round Back
Model: 992365
24.75W 22.5D 39H
25AH




Toni Stacking Chair, Queen Anne Legs, Classic T Arm, Seat Pad, Round Back
Model: 992405
26W 22.5D 39H
26AH




Toni Stacking Chair, Queen Anne Legs, Classic T Arm, Plush Seat, Round Back
Model: 992465
26W 22.5D 39H
26AH




Toni Stacking Side Chair, Contemporary Legs, Armless, Seat Pad, Round Back
Model: 997005
19.75W 22.5D 39H




Toni Stacking Side Chair, Contemporary Legs, Armless, Plush Seat, Round Back
Model: 997065
20.75W 22.5D 39H




Toni Stacking Chair, Contemporary Legs, Straight T Arm, Seat Pad, Round Back
Model: 997105
24.75W 22.5D 39H
25AH




Toni Stacking Chair, Contemporary Legs, Straight T Arm, Plush Seat, Round Back
Model: 997165
24.75W 22.5D 39H
25AH




Toni Stacking Chair, Contemporary Legs, Gooseneck Arm, Seat Pad, Round Back
Model: 997205
24.75W 22.5D 39H
25.5AH




Toni Stacking Chair, Contemporary Legs, Gooseneck Arm, Plush Seat, Round Back
Model: 997265
24.75W 22.5D 39H
25.5AH




Toni Stacking Chair, Contemporary Legs, Waterfall Arm, Seat Pad, Round Back
Model: 997305
24.75W 22.5D 39H
25AH



Toni Stacking Chair, Contemporary Legs, Waterfall Arm, Plush Seat, Round Back
Model: 997365
24.75W 22.5D 39H
25AH




Toni Stacking Chair, Contemporary Legs, Classic T Arm, Seat Pad, Round Back
Model: 997405
26W 22.5D 39H
26AH




Toni Stacking Chair, Contemporary Legs, Classic T Arm, Plush Seat, Round Back
Model: 997465
26W 22.5D 39H
26AH


Toni Dining




Toni Side Chair, Queen Anne
Legs, Armless, Seat Pad,
Round Back
Model: 92005
24.75W 22.5D 39H




Toni Side Chair, Queen Anne
Legs, Armless, Plush Seat,
Round Back
Model: 92065
24.75W 22.5D 39H




Toni Dining Chair, Queen
Anne Legs, Straight T Arm,
Seat Pad, Round Back
Model: 92105
23.5W 22.5D 39H
25AH



Toni Dining Chair, Queen
Anne Legs, Straight T Arm,
Plush Seat, Round Back
Model: 92165
23.5W 22.5D 39H
25AH




Toni Dining Chair, Queen
Anne Legs, Gooseneck Arm,
Seat Pad, Round Back
Model: 92205
24W 22.5D 39H
25.5AH




Toni Dining Chair, Queen
Anne Legs, Gooseneck Arm,
Plush Seat, Round Back
Model: 92265
24W 22.5D 39H
25.5AH




Toni Dining Chair, Queen
Anne Legs, Waterfall Arm,
Seat Pad, Round Back
Model: 92305
24.75W 22.5D 39H
25AH




Toni Dining Chair, Queen
Anne Legs, Waterfall Arm,
Plush Seat, Round Back
Model: 92365
24.75W 22.5D 39H
25AH




Toni Dining Chair, Queen
Anne Legs, Classic T Arm,
Seat Pad, Round Back
Model: 92405
26W 22.5D 39H
25AH




Toni Dining Chair, Queen
Anne Legs, Classic T Arm,
Plush Seat, Round Back
Model: 92465
26W 22.5D 39H
25AH




Toni Side Chair,
Contemporary Legs,
Armless, Seat Pad, Round
Back
Model: 97005
24.75W 22.5D 39H




Toni Side Chair,
Contemporary Legs,
Armless, Plush Seat, Round
Back
Model: 97065
24.75W 22.5D 39H




Toni Dining Chair,
Contemporary Legs, Straight
T Arm, Seat Pad, Round
Back
Model: 97105
23.5W 22.5D 39H
25AH




Toni Dining Chair,
Contemporary Legs, Straight
T Arm, Plush Seat, Round
Back
Model: 97165
23.5W 22.5D 39H
25AH




Toni Dining Chair,
Contemporary Legs,
Gooseneck Arm, Seat Pad,
Round Back
Model: 97205
24.75W 22.5D 39H
25.5AH




Toni Dining Chair,
Contemporary Legs,
Gooseneck Arm, Plush Seat,
Round Back
Model: 97265
24.75W 22.5D 39H
25.5AH




Toni Dining Chair,
Contemporary Legs,
Waterfall Arm, Seat Pad,
Round Back
Model: 97305
24.75W 22.5D 39H
25AH



Toni Dining Chair,
Contemporary Legs,
Waterfall Arm, Plush Seat,
Round Back
Model: 97365
24.75W 22.5D 39H
25AH



Toni Dining Chair,
Contemporary Legs, Classic
T Arm, Seat Pad, Round
Back
Model: 97405
26W 22.5D 39H
25AH



Toni Dining Chair,
Contemporary Legs, Classic
T Arm, Plush Seat, Round
Back
Model: 97465
26W 22.5D 39H
25AH